

Using the Corvette navigation system - Index and Quick reference. by Paul Pearson

<u>Section</u>	<u>Document</u>	<u>'08 Nav manual reference</u>	<u>Page</u>
Section 1. Setting up the navigation system. – Part 1		1-7	page 5.
Setting the correct region		1-7	page 6.
User settings		2-41	page 7.
Quick points of interest		2-37	page 8.
Section 2 Entering a destination	Part 1,	2-4	page 9.
Menu selections			page 9
Entering an address		2-7	page 10.
Route options - route info		2-22	page 12.
Route options – cancel guidance		1-11	page 14
Display route		2-46	page 15
Turn list		2-46	page 15
Section 3 Other means of destination entry	Part 2		page 17.
Select from map		2-11	page 18.
Phone number		2-17	page 19.
Section 4. Points of Interest	Part 2.	2-8	page 21.
POI by city or name		2-8	page 22.
POI by Quick POI or map			page 25.
POI Info			page 26.
POI voice recognition commands		4-8	page 27.
Section 5. Waypoints	Part 3		page 28.
Storing waypoints via the Enter Destination menu		2-30	page 29.
Storing waypoints via the Destination and Waypoint menu			page 31.
Section 6. Storing a memory point	Part 3	2-24	page 32.
Storing a memory point from the map screen			page 34.
Adding or editing a memory point name		2-23	page 36.
Adding or editing a memory point phone number		2-26	page 36.
Deleting one or all memory points		2-27	page 38.
Section 7. Previous destinations	Part 4		page 39
Using a previous start point		2-14	page 40.
Using a previous destination from the list		2-14	page 41.
Section 8. Preset destinations	Part 4		page 42.
Entering a Preset destination		2-33	page 42.
Editing a Preset destination		2-34	page 43.
Using a preset destination.		2-19	page 44.
Section 9. Map modes	Part 5		page 46.
Single map mode		2-56	page 47.
Dual map mode		2-57	page 48.
Turn list map mode		2-57	page 48.
Next turn map mode		2-57	page 49.
Highway guidance map mode		2-58	page 49.
Section 10. Functions avail. while driving.	Part 6		page 51.
Navigation System quick reference sheet			page 58.